

**nutribullet 600W
Personal Blender:
The Original
Nutrient Extractor.**



nutribullet®

The original nutribullet® has everything you need to take that first step toward a healthier lifestyle. Its secret weapon? Nutrient extraction: the fine blending that turns ordinary food into superfood. nutribullet's® sharp blades and powerful 600-Watt motor effortlessly blend fruits, vegetables, liquids and so much more into nutritious smoothies, simply and deliciously delivering key nutrients to your body. Just push, twist and blend to make almost any smoothie in under 60 seconds.



Model Number	NB606DG
Wattage	600W
Colors	Grey
Included	<p>600W Motor Base Stainless Steel Extractor Blade 700mL Tritan Cup 500mL Tritan Cup Drink Ring Handled Drink Ring</p>



The original nutrient extractor. Turn ordinary food into superfood.



Essential Design.

Simple and intuitive.
Just push, twist and blend.

BPA-Free Tritan Cups.

Strong and durable.
Blend and drink from
the same cups.

Extractor Blade.

Powerful stainless steel blade designed for optimum
nutrient extraction™.

600-Watt Motor.

Compact powerhouse turns food from
strawberries to spinach into smooth, sippable nutrition.

	Free load speed (RPM)	On-load speed (RPM)	Max torque(N.m) -measured data	speed at rated power(RPM) -measured data	Torque at rated power (N.m) -measured data
NB 600W	18500±15%RPM	11000±1500RPM	0.95N.m	7500RPM	0.35N.m

- No motorbase timeout/interrupt, recommendation is not to blend longer than 1 minute at a time.
- If you need to blend for longer than one minute, blend for 1-minute intervals. After the initial and each subsequent 1-minute blending cycle, allow the motor base to shut off completely and wait at least one minute before starting another cycle.
- Do not run for more than 3 consecutive 1-minute intervals to prevent the contents from overheating. Allow contents to settle for 2-3 minutes after the third extraction cycle to prevent overheating and buildup of pressure.



- For regular use to blend smoothies, dips, snacks, dressing
- Blade material: Stainless Steel
- Blade thickness: 1.2mm
- Blade should be replaced every 6 months

DO NOT BLEND/GRIND:

- For longer than 1 minute at a time
 - Without liquid in cup
- Hot or carbonated ingredients
 - Coffee beans
- Peppercorns or hard spices

**1**

Add ingredients* to the NutriBullet® cup.

**2**

Place the extractor blade onto the cup and twist until it is tightly sealed.

**3**

Turn the cup upside down and place it onto the motor base, gently push and twist


**4**

To turn off the NutriBullet® — simply twist in the opposite direction (counterclockwise) and remove cup from base.

**5**

Once the extractor blade stops completely, remove the cup from the motor base. Enjoy!

1. You must always add liquid before you blend a smoothie
2. Don't overfill your cup. Make sure your ingredients and liquid reach no higher than the MAX line.
3. For a cooler, more flavorful smoothie, we recommend using frozen fruit and/or veggies. You can also add ice but not more than 25% of the cup's total volume.



- Recommended to wash blade by hand.
- Cups and accessories are top rack dishwasher safe; do not use when running sanitize cycle.
- Motor base should be unplugged and wiped with warm, soapy cloth.
- Cups are NOT microwave or freezer safe.
- Blade gasket is NOT designed to be removed. If gasket becomes worn, torn or lose, blade must be replaced.



THANK YOU