

General Info and Specifications

Sensors

Four load cells measure weight.

Limitations

- The scale's weight limit is: 397lbs, 28st: 5lbs, or 180kg.
- Aria Air isn't serviceable. If you need assistance with your scale, contact [Customer Support](#).

Batteries

- 3 alkaline 4.5V size AAA batteries included

To change the batteries in Aria Air:

1. On the back of your scale, pull up on the tab to remove the cover from the battery compartment.
2. Remove the batteries.
3. Insert 3 alkaline 4.5V size AAA batteries.
4. Return the cover to the battery compartment and press down until it's secure.
5. Turn over your scale and wait a few moments for Aria Air to calibrate before starting a weigh-in.

Size and weight

Length	Width	Depth	Weight
300mm	300mm	25.7mm	1.79kg

Environmental conditions

Operating Temperature	41° to 104° F (5° to 40° C)
Non-operating Temperature	-4° to 41° F (-20° to 5° C) 104° to 140°F (40° to 60° C)
Relative Humidity	Up to 90% RH Aria Air is designed to operate in a humid bathroom environment.
Environmental Pressure Range	86kPa to 106kPa

Care and maintenance

Clean Aria Air as needed. To clean your scale, follow these tips:

- Wipe down the surface with a damp cloth using a mild detergent before your first use.
- Do not submerge Aria Air or use high-pressure water jets (for example, shower head) to clean the surface.
- Do not use antiseptic wipes, chlorine, or highly concentrated glass cleaner on the surface of the scale.
- Do not use abrasive cleaners to clean your scale.

Learn more

To learn more about your scale, how to track your progress in the Fitbit app, and how to build healthy habits with Fitbit Premium, visit help.fitbit.com.

Return policy and warranty

Find warranty information and the fitbit.com return policy at [fitbit.com/legal/returns-and-warranty](https://www.fitbit.com/legal/returns-and-warranty).